


Quick start guide Climapro₁ / Climapro₁ RF

Glow•worm



- 1 information area
- 2 room temperature
- 3 current time and date
- 4 outdoor temperature (outdoor sensor option)

Buttons:

	back to previous setting or menu
	main menu access
	choose a menu, set a value
	choose a menu, set a value
	confirm the selection or setting

Pictograms:

	keys locked
	holidays defined
	holidays activated
	annual service reminder
	change batteries (wireless version)

MAIN MENU

FUNCTIONS AVAILABLE

Heating



on/off

program

Hot water



override

temperature

Holiday



date/time

language

control name

Parameters



lock keypad

display

Efficiency info



reset

about

The menus displayed depends on the installation options (check with your installer)



* 2 7 0 2 7 3 8 R E V 0 *

0020132041_00 - 11/11