MIGO LINK APP USER GUIDE



glow ╬ worm


Dashboard features

All in one place

The MiGo Link app allows you to control your heating on the go*. With full visibility of your heating, you can easily adjust the temperature and more...

The dashboard lets you...


- See your heating's status at a glance
- Check the indoor and outdoor climate
- Access all main functions from one central place V
- If you have a MiGo Select control, you will also \checkmark be able to see room humidity



App version 2.11.2

^{*} A MiGo Link Internet gateway must be installed with either a MiSet, MiGo Select or Climastat Select control for app compatibility.

How to change your heating mode



By selecting the top left option on the app screen, you can manually change the modes of your heating.

Time Control

follows the time programmes saved in the weekly planner in the app.

Manual

follows the temperatures set, turn it up when you want it on and down when you want it off.

Heating Off

turns the heating off and will only turn on if the room falls below the set back temperature.

Manual override

Maximum flexibility


If you've set your heating mode to 'time control' but want to temporarily change the room temperature, simply use the + or - to override the system.

When your plans change, you can:

- ✓ Temporarily override your automated settings
- ✓ Quickly adjust the temperature manually




Use the + and – to adjust your desired temperature



And set a timer for the manual override

Away function and hot water boost






Energy information

Water pressure 1.2 bar DHW temperature 60.0° Actual flow temperature (Heating circuit 1) 50.0°	SYSTEM INFORMATION Water pressure DHW temperature 60.0* Actual flow temperature (Heating circuit 1) 50.0* GATEWAY SR 940f SN: 21233700202920130933133263N5	10:51	.ıl 🕆 🔽
Water pressure 1.2 bar DHW temperature 60.0° Actual flow temperature (Heating circuit 1) 50.0° GATEWAY SR 940f SN: 21233700202920130933133263N5	Water pressure 1.2 bar DHW temperature 60.0° Actual flow temperature (Heating circuit 1) 50.0° GATEWAY SR 940f SN: 21233700202920130933133263N5	← Energy information	
DHW temperature 60.0° Actual flow temperature (Heating circuit 1) 50.0° GATEWAY SR 940f SN: 21233700202920130933133263N5	DHW temperature 60.0* Actual flow temperature (Heating circuit 1) 50.0* GATEWAY SR 940f SN: 21233700202920130933133263N5	SYSTEM INFORMATION	
Actual flow temperature (Heating circuit 1) 50.0* SATEWAY SR 940f SN: 21233700202920130933133263N5 5	Actual flow temperature (Heating circuit 1) 50.0* GATEWAY SR 940f SN: 21233700202920130933133263N5 5	Water pressure	1.2 bar
SATEWAY SR 940f SN: 21233700202920130933133263N5	GATEWAY SR 940f SN: 21233700202920130933133263N5	DHW temperature	60.0°
SR 940f SN: 21233700202920130933133263N5	SR 940f SN: 21233700202920130933133263N5	Actual flow temperature (Heating circuit 1)	50.0°
SN: 21233700202920130933133263N5	SN: 21233700202920130933133263N5	GATEWAY	
		SR 940f	

From here, you can see how your heating is performing

Weekly planner




Setback temp	These let you select the operation mode for this zone, create or edit a schedule for each day of the week and change the temperatures.	10:52 ←	Heatin	• • • • • • • • • • • • • • • • • • •	2	
Image: Setback temp. 15.0°C Go to the next page	Image: Setback temp. 15.0°C Go to the next page	These this zoi	let you select the op ne, create or edit a	peration mode for schedule for each	:S.	
Go to the next page	Go to the next page		ekly planner		>	
Setback temp. 15.0°C > next page	Setback temp. 15.0°C > next page	🔏 Op	eration mode	Time-contr.	>	
E Temp. (Manual)	E Temp. (Manual)	🤇 Se	tback temp.	15.0°C	>	Go to the next pag
		🤱 Tei	np. (Manual)	24.0°C	>	
		. Tei	np. (Manual)	24.0°C	>	
)

Select: Weekly Planner


Weekly planner (continued)

Now that you have selected 'weekly planner', you can add and edit time periods for your heating, and copy settings across different days.



Alter time programmes

Add multiple time periods for each day



Copy time periods across days

Frequently asked questions

Where can I set my password and what are the password requirements for the MiGo Link app?

A password for the MiGo Link app has a minimum length of 8 characters, and must contain at least 1 of each: an upper-case letter, lower-case letter, numerical digit and a special character.

The password will be set as part of creating your MiGo Link account.

What do I need to use the MiGo Link app?

You will need a Glow-worm boiler with a MiGo Link internet gateway and one of the following thermostats: MiSet, MiGo Select or Climastat Select.

Where can I download the MiGo Link app?

You may download the MiGo Link app from the Apple App Store or Google Play Store.

Minimum of iOS 13.4 or Android 8 is required.

How do I update the MiGo Link app?


Depending on your phone settings, your app may automatically update. If It doesn't, you may update the app through the Apple App Store and Google Play Store.

How can I send feedback, ask questions, or report concerns from within the MiGo Link app? (e.g, security issues)

If you would like to submit any query, concern or feedback, please use the 'Send feedback' function in the app.

To access the 'Send feedback' function, select the settings in the bottom left of the app screen and you will see 'Send feedback' toward the bottom of the screen.

Once your message has been raised, our app support team will reply and update you by email. Replies will be sent to the email address used to set up the MiGo Link account.



Get in touch

For expert advice on Glow-worm controls or any other products, speak to your local installer.

You can find installers in your area, as well as further information on Glow-worm, at **glow-worm.co.uk** or scan the QR code below.





glow ╬ worm

Glow-worm

Nottingham Road Belper Derbyshire DE56 1JT

0345 602 2922



WHY CHOOSE A CLUB ENERGY INSTALLER?

Club Energy is Glow-worm's installer loyalty scheme. By choosing a Club Energy installer, you're choosing a Gas Safe registered, independent expert who can offer you exclusive extended guarantees and more.

GWLFTAPPGUIDE0424